



WELD-ON APPLICATOR SELECTION GUIDE

Weld-On solvent cements are packaged with can-lid daubers: 3/4" dauber on quarter pint and half pint cans and 1/2" dauber on pint and quart cans. For proper solvent welding of pipe and fittings, the cement applicator **must** be no less than half the size of the pipe. See the following charts for applicator (daubers, swabs, and rollers) recommendations pertaining to pipe size.

| DAUBERS | Pipe Diameters | | | | | | |
|---------------|----------------|------|------|----|--------|--------|----|
| | 1/4" | 1/2" | 3/4" | 1" | 1 1/4" | 1 1/2" | 2" |
| 3/8" Dauber | . | . | . | | | | |
| 1/2" Dauber | | | . | . | | | |
| 3/4" Dauber | | | | | . | . | |
| 1 1/2" Dauber | | | | | | | . |

| ROLLERS & SWABS | SIZE | FOR PIPE DIAMETERS |
|-----------------|-----------|--------------------|
| 3020 | 3" Roller | 3" - 6" |
| 6020 | 4" Roller | 3" - 8" |
| 7020 | 7" Roller | 6"+ |
| 4020 | 4" Swab | 6"+ |
| 5020 | 4" Swab | 3" - 8" |
| 8020 | 4" Swab | 6"+ |
| SuperSwab™ | 4" Swab | 4" - 8" |

