

WELD-ON®

W e t C o n d i t i o n s T i p s

Specific precautions should be taken when working with solvent cement in wet conditions. Follow these simple guidelines to ensure the best possible results for your piping system.

Internal flow in piping system should be completely stopped. Keep pipe as dry as possible and wipe clean before cement application.

Detenga completamente el flujo interno en el sistema de tubería. Mantenga la tubería lo más seca posible y limpie con un trapo antes de la aplicar el cemento.



However, Weld-On 725™ Wet 'R Dry, 737™ Turf 'N Ag, 738™ Hot 'N Fast, and 750™ HotWeld are specially formulated for wet conditions, with fast acting solvents that evaporate quickly even in low temperatures.

Sin embargo, los cementos Weld-On® 725™ Wet 'R Dry, 737™ Turf 'N Ag, 738™ Hot 'N Fast, y 750™ HotWeld están especialmente formulados para condiciones húmedas y con disolventes de pronta acción que se evaporan rápidamente, incluso a bajas temperaturas.

When dealing with wet conditions, always hold a newly solvent welded pipe and fitting together for longer than the typical duration of 30 seconds.

Cuando se trabaje en condiciones húmedas, mantenga la tubería y la conexión recién soldadas juntas por más tiempo de los 30 segundos requeridos.



Follow and Like us:



[twitter.com / WeldOnCements](https://twitter.com/WeldOnCements)
[facebook.com / WeldOnCements](https://facebook.com/WeldOnCements)

